

WinVent - Update


E.1 WinVent Software 2016 and older

The former Kühner update server no longer exists! An update via the built-in update function is therefore no longer possible. This software can only be updated as follows:

1. Load and run **WinVent 4.0 Software for Windows 7...11**
2. Select the previous WinVent directory (Browse)
3. Start installation (if necessary, select the "Repair" option)
Your previous settings and data remain unchanged!

E.2 WinVent Software 2017 and newer

Select and start the update function. Everything else is done automatically.



D.1 WinVent Software 2016 und älter

Der ehemalige Kühner-Update-Server existiert nicht mehr! Ein Update über die eingebaute Update-Funktion ist deshalb nicht mehr möglich. Diese Software kann nur wie folgt aktualisiert werden:

1. **WinVent 4.0 Software für Windows 7...11** laden und ausführen.
2. Das bisherige WinVent-Verzeichnis auswählen (Browse)
3. Installation starten (allenfalls die Option „Repair“ wählen)
Ihre bisherigen Einstellungen und Daten bleiben unverändert erhalten!

D.2 WinVent Software 2017 und neuer

Die Update-Funktion auswählen und starten. Alles weitere erfolgt automatisch.

